Channe	el. Instrument.	Sugg. Mic / Di.	
1.	KICK 1	D112 or ß52	
2.	SNARE	SM57 or ß57A	
3.	HATS	C451 or SM81	
4.	RACK TOM	E604 or SM98 or SM57	
5.	FLOOR TOM	E604 or SM98 or SM57	
6.	OVERHEAD (left)	414 or C1000	
7.	OVERHEAD (Right)	414 or C1000	
8.	BASS	Active DI	
9.	GUITAR (Stage Left)	SM57 or E609	
10.	VOX 1 (Stage Left, Guitar)	SM58 or ß58	In-Ear Monitors (supplied)
11.	VOX 2 (Centre, Vocalist)	SM58 or ß58	In-Ear Monitors (supplied)
12.	VOX 3 (Drummer)	SM58 or ß58	In-Ear Monitors (supplied)

Power Socket to suit UK spec 3-pin Plugs. 8 in total.

A Straight (NOT BOOM) mic stand for Lead Vocals.